

VPOD Blank Panel Installation Instructions



Parts Description

VPOD Vertical Blank Panel
(4) Shoulder Bolts



Required Tools

5/32 Allen Tool



1 Make sure both cabinets that the Blank will be installed between, are level and properly bayed together using all (4) baying brackets. See Baying Instructions.



2 Install the (4) shoulder bolts provided onto the inside of the VPOD Frame as shown, using the 5/32" Allen Tool. (2) bolts on the top and (2) bolts on the bottom.



3 Place the Blank over the (4) shoulder bolts and hook the back plate into place.

To assist safe installations, comply with the following:

- A. Use caution when installing or modifying telecommunications circuits.
- B. Never touch uninsulated wire terminals unless the circuit has been disconnected.
- C. Never install this device in a wet location.
- D. Never install wiring during a lightning storm.

Global Headquarters
Watertown, Connecticut USA
Tel: (1) 866-548-5814

For a complete listing of our global offices visit our web site

