

# S110<sup>®</sup> 4-Pair Termination Tool

**Seats 3-, 4-, and 5-pair 110 blocks**

- **Replaceable head and cutting blades**
- **Terminates wires on both the cable and the cross-connect side of 110 blocks**
- **Compact design can be used with disconnect or modular jack panel 110 blocks**
- **Compatible with 4-pair work area products**
- **Ergonomically designed handle**



**1** To remove the head of the tool for blade replacement, twist and pull the head from the tool body.




**2** Slide the trimming blades and wire seating assembly out of tool head.

**Caution:** Blades are extremely sharp. Exercise caution when handling.



**3** Remove the cutting blades from the assembly. Rotate 180° and place back into position.



**4** Slide the combined trimming blade/seating assembly back into position inside the tool head. Examine the assembly to ensure proper alignment of all components.



**5** Snap the head onto the shaft of the tool and rotate it until it locks into position.



**6** Terminate and trim the conductors into the 110 wiring base using the cutting edge of the tool.



**7** Insert a 110C connecting block into the head of the tool, carefully align over the wiring base and punch down on the block.



**8** Lace cross-connect cable into the 110C block and terminate.

# Ordering Information

## Ordering Information

S788J4H .....Replacement head

S788J4B.....Cutting blades

### To assist safe installations, comply with the following:

- A. Use caution when installing or modifying telecommunications circuits.
- B. Never touch uninsulated wire terminals unless the circuit has been disconnected.
- C. Never install this device in a wet location.
- D. Never install wiring during a lightning storm.



#### Worldwide Headquarters North America

Watertown, CT USA  
Phone (1) 860 945 4200 US  
Phone (1) 888 425 6165

#### Regional Headquarters EMEA

Europe/Middle East/Africa  
Surrey, England  
Phone (44) 0 1932 571771

#### Regional Headquarters Asia/Pacific

Shanghai, P.R. China  
Phone (86) 21 5385 0303

#### Regional Headquarters Latin America

Bogota, Colombia  
Phone (571) 657 1950