



UAB Stainless Steel Faceplate Instructions




PEEL BACK AND REMOVE PAPER BACKING FROM TRANSPARENT ADHESIVE SPACER


1



BACK VIEW (4-PORT): APPLY SPACER TO BACK OF PLATE. SPACER MUST BE FLUSH ON TOP AND BOTTOM OF OPENING



2



SIEMON™

www.siemon.com

Global Headquarters

Watertown, Connecticut USA

Tel: (1) 866-548-5814

For a complete listing of our global offices visit our web site

